

## Cross Reference - Borg Warner (Schwitzer) to Melett

OE Number	Melett No	Description
22366	1250-040-100	Bearing (4LE- HC3 -HT3B -K361)
51948	1250-030-150	O Ring - (Insert 65mm)
52799	1250-040-155	O Ring - (4LE/F/GK C/Hsg to B/Hsg Red)
52869	1250-040-320	Thrust Bearing (4LE-4LGK-4LG - No Ramping)
57753	1250-040-260	Oil Control Sleeve
125638	1250-404-350	Shaft Nut 4MD ( Nylock)
125647	1150-400-170	Piston Ring
125648	1250-404-250	Shim (4MD-4HD) .002" (21.30 O.D., 12.85 I.D.)
125649	1250-404-251	Shim (4MD-4HD) .005" (21.30 O.D., 12.85 I.D.)
125650	1250-404-252	Shim (4MD-4HD) .010" (21.30 O.D., 12.85 I.D.)
127305	1250-403-140	Snap Ring (Insert retainer)
128565	1250-404-405	C/W 4MD-458
128936	1252-103-170	Piston Ring 3LM/S3A Comp End ssb 310279
129109	1100-040-180	Piston Ring T04B T/end
129119	1900-000-035	Gasket. Oil Inlet T12
129119	1900-000-036	Gasket 3LD Oil Intlet
129120	1900-000-025	Gasket. Oil Outlet T12
129533	1250-404-142	Snap Ring (Turb. Back Plate) 4MD
129577	1152-303-170	Piston Ring
130087	1152-302-140	Snap Ring H2C / 3LKS
130282	1301-036-140	Snap Ring (H.S.K)
130665	1100-120-645	Nut. V Band clamp. T12 ssb 510927
130665	1250-404-645	Nut (V Band clamp T & C)
132040	1900-000-003	Gasket
133125	1250-404-346	V Band Clamp Assy Comp/Hsg 9"
134058	1250-404-140	Snap Ring (4MD/HD/T14 Bore)
135209	1150-400-160	Piston Ring (HCSKM)
135619	1250-404-100	Bearing 4MD/HD (Grooved ends & Grooved ID)
135624	1250-404-402	Compressor Wheel 4MD-354
135625	1250-404-404	Compressor Wheel 4MD-454
135947	1250-404-340	Heat Shield 4MD
135955	1250-404-240	Thrust Ring ssb 140963
136017	1250-404-409	Compressor Wheel 4MD-754
136700	1250-404-345	V Band Clamp 4MD 7" (Turb.end)
137008	1100-120-610	Bolt. (Insert Plate) T12
137016	1250-404-220	Spacer Sleeve 4MD
137017	1250-404-550	Lock tab 4MD / 4HD (Thrust Brg Ret)ss/by 1250404580
137281	1250-404-900	Nozzle Ring 4MD .318
137856	1250-404-310	Thrust Bearing Cover 4MD
137943	1250-404-320	Thrust Bearing 4MD (ssb 140964)
137945	1250-404-330	Thrust Plate 4MD
138178	1250-404-901	Nozzle Ring 4MD .246
138363	1250-040-100	Bearing (4LE- HC3 -HT3B -K361) Std OD/ Std ID
138991	1250-404-435	Shaft and Wheel 4MD ssb 181474
138992	1250-404-435	Shaft and Wheel 4MD ssb 181474
139051	1250-404-150	O Ring (Insert ) 4MD
139052	1250-404-141	Snap Ring (Inset ) 4MD
139053	1250-404-300	Insert Plate 4MD
139055	1252-004-100	Bearing S4T Std/Std
139265	1250-404-155	O Ring V 4MD- K37 C/Hsg To S/P
139572	1301-036-220	Spacer Sleeve (4LE/K36)
140029	1250-404-260	Oil Control Sleeve (4"-4MD)

OE Number	Melett No	Description
140388	1250-404-435	Shaft & Wheel (ssb 181477)
140389	1250-404-435	Shaft & Wheel (ssb 181477)
140647	1250-404-405	Compressor Wheel 4MD-458
140886	1250-404-411	Compressor Wheel 4MD-755>
140963	1250-404-240	Thrust Ring 4MD
140964	1250-404-320	Thrust Bearing 4MD (ss137943) ssb186891
140964	1250-404-321	Thrust Bearing 4HD/4MD
141073	1250-040-350	Shaft nut (4LE/F/GK)
141419	1250-404-450	Bearing Housing 4MD UNC (No lugs) >
141525	1250-403-240	Thrust Ring 3LD
142066	1250-403-300	Insert Plate
142114	1150-400-172	Piston Ring ssb 310503
142228	1250-040-155	O Ring (4LE/F/GK) C/Hsg to B/Hsg
142229	1250-040-260	Oil Control Sleeve (4LE)
143000	1250-030-150	O Ring (Insert HSKM)
143137	1250-404-400	Compressor Wheel 4MD-351
143166	1250-404-408	Compressor Wheel 4MD-659
143823	1100-120-350	Shaft Nut
143823	1250-403-350	Shaft Nut 3LD (Nylock)
144077	1250-403-200	Thrust Spacer 3LD (Single Groove)
144078	1250-403-310	Oil Deflector 3LD (narrow tongue)
144079	1250-403-320	Thrust Bearing 3LD
144080	1150-403-100	Bearing 3LD (Std)
144080	1250-403-100	Bearing 3LD Schwitzer Type (use 1150403100)
144083	1250-403-435	Shaft / Wheel (1 groove) ssb 156689
144127	1250-404-406	Compressor Wheel 4MD-558
144334	1301-036-240	Thrust Ring
144538	1250-504-401	Comp Wheel 4LE 504 Radial
144834	1250-403-645	V Clamp
145108	1200-050-630	Washer (2 Piece clamp Plate)
146594	1250-403-426	Comp. Wheel 3LD-1 / 279
146595	1250-403-425	C/Wheel 259 / 3LD9
146608	1252-103-150	'O' Ring - Red Silicon - S3 (C/Cvr to B/Hsg)
146627	1250-403-561	Bolt
146643	1250-403-800	Comp Cover 259 / 3LD9 8 x M6-6H
146643	1250-403-801	Comp. Housing 3LD-9 / 259 Metric Thread
146739	1250-404-320	Thrust Bearing 4MD
146740	1250-404-100	Bearing 4MD/HD (Grooved ends & Grooved ID)
146741	1100-120-610	Bolt. (Insert Plate) T12
146791	1100-120-610	Bolt. (Insert Plate) T12
146808	1150-400-160	Piston Ring (HCSKM) Stainless
147427	1301-027-500	Clamp Plate (3LD/3LEP/K27 Comp.)
147571	1250-403-802	Comp. Housing 3LD-1 / 279 UNC Thread
147620	1250-403-425	C/Wheel 259 / 3LD9
147643	1100-120-350	Shaft Nut 3LD
147837	1900-000-037	Gasket (Oil Inlet) 3LM / S2A
148225	1250-040-120	Bearing 4L +0.010" OD/- .010"ID
148313	1301-027-500	Clamp Plate (3LD/3LEP/K27 Comp.)
148337	1150-504-200	Flinger Sleeve 4LE 2 ring groove (MELETTx 2 parts)
149403	1250-403-435	Shaft / Wheel (1 groove) ssb 156689
149925	1250-040-350	Shaft nut (4LE/F/GK)
151242	1250-030-150	'O' ring
151242	1250-030-150	O Ring (Insert HSKM)
152408	1301-036-240	Thrust Ring

OE Number	Melett No	Description
155434	1152-302-160	Piston Ring (H1C/H2C/3FD/J) Turb.End
156650	1250-403-645	V Clamp
156656	1250-403-435	Shaft / Wheel (1 groove)
156689	1250-403-435	Shaft & Wheel 3LD (Single groove)
156768	1250-403-645	V Band Clamp 3LD (T/Hsg to B/Hsg)
158144	1250-403-321	Thrust Bearing 3LM
158147	1250-040-124	Bearing 4LE /F/G OD +.010" / Std ID
158185	1250-040-320	Thrust Bearing (4L-/HC3/3LKS)
158567	1250-404-620	Bolt.(Insert Plate)10-24x1
158726	1150-513-300	Insert Plate 3FJ/3LM
158979	1250-403-450	Bearing Housing 3LD (Step Bore UNC & Ford)
159177	1250-403-561	Bolt (Comp. Hsg) UNC
159608	1250-040-400	Comp Wheel 4LE 302 Radial
166084	1150-704-300	Insert Plate 4LGK/HC3
166118	1252-419-124	Bearing S4A/D +.010"OD / Std ID
166119	1252-419-137	Bearing S4A/D +.020"OD / Std ID
166120	1252-419-120	Bearing S4A/D +.010"OD / -.010" ID
166121	1252-419-127	Bearing S4A/D Std. OD /-0.010" ID
166496	1252-103-350	Shaft Nut (Flanged) 12 Point S3A/B LHT
167051	1152-304-401	C/W HT3B
167416	1253-300-100	Journal Bearing S300 Std/Std
167492	1152-301-351	Shaft Nut S2B LHT
167551	1253-400-170	Piston Ring S300/S400 (Comp.)
167657	1253-200-100	Journal Bearing S200 Std/Std
167747	1253-200-170	Piston Ring S200 (Comp.)
167782	1253-500-170	Piston Ring S500 Comp End
167787	1253-400-100	Bearing S400 Std/Std
168084	1150-704-300	Insert Plate 4LGK/HC3
168508	1100-030-351	Shaft Nut S2A LHT
169707	1253-400-163	Piston Ring S400 (Turb. 26mm OD / Twin Ring Shaft)
169947	1252-201-320	Thrust Bearing S1B
171519	1253-500-160	Piston Ring S500 Turb End Std/Std
181253	1250-040-350	Shaft nut (4LE/F/GK)
181474	1250-404-435	Shaft and Wheel 4MD ss 138992
181477	1250-404-435	Shaft & Wheel 4MD
181750	1150-403-750	Repair Kit 3LD
181751	1301-504-752	Service Kit 4LE/4LF
181836	1250-404-753	OVERHAUL KIT ssb 318357
181929	1251-133-100	Bearing 3LM Std/Std
182042	1301-027-160	Piston Ring K26
182185	1250-404-451	Bearing Housing 4MD Metric 8mm (No lugs)
182195	1250-040-751	REPAIR KIT 4L
182196	1250-404-413	Compressor Wheel 4MD-759
182283	1250-403-861	Turbine Hsg 3LD(Twin port-bolt discharge-UNC) 2.24
182307	1152-303-435	Shaft & Wheel (HC3/K361) UNF T3
182353	1250-504-401	Comp Wheel 4LE504
182561	1152-303-320	Thrust Bearing 4LEG (Ramped)
182598	1250-403-860	Turbine Housing 3LD 2.17 (Twin port-bolt discharge-Metric)
182668	1100-120-350	Shaft Nut 3LD
182669	1250-040-350	Shaft nut (4LE/F/GK)
182670	1250-404-350	Shaft Nut 4MD (Nylock)
182674	1100-120-350	Shaft Nut 3LD
183189	1250-404-320	Thrust Bearing 4MD (can use -321)
183199	1250-403-425	Comp. Wheel 3LD-9 / 259

OE Number	Melett No	Description
183212	1250-404-753	OVERHAUL KIT 4MD
183214	1250-404-750	Service Kit 4MD (Inc Gaskets)
183224	1250-403-753	Service Kit, Major (3LD/J Step P/R & T/R)
183466	1152-303-436	Shaft & Wheel (HC3 UNF T2)
183472	1150-704-300	Insert Plate 4LGK/HC3
183482	1250-404-580	Washer Spring 4MD/4HD(Brg Ret) 3/16 ss 550/630
183482	1250-404-630	Spring Washer (L/Tab-T/Brg) 4MD/4HD ssb 580
183542	1150-413-100	Bearing 3FD/FJ ODSd/IDStd
183547	1301-036-220	Spacer Sleeve (4LE/K36)
185104	1200-050-435	Shaft & Wheel (T50) ssb 1200050436
185288	1150-403-100	Bearing 3LD (Std) Tin Plated
185727	1250-040-350	Shaft nut (4LE/F/GK)
185854	1250-040-127	Bearing 4L Std OD/-0.010"ID
185859	1250-404-127	Bearing 4MD/4HD Std OD/-10 ID (Grv ID & End)
186135	1152-302-160	Piston Ring (H1C/H2C/3FD/J) Turb.End
186148	1250-404-100	Bearing 4MD/HD (Grooved ends & Grooved ID)
186558	1250-040-320	Thrust Bearing (4L-/HC3/3LKS) ssb 182561
186648	1152-303-435	Shaft & Wheel (HC3/K361) UNF T3
186649	1152-303-436	Shaft & Wheel (HC3 UNF T2)
186790	1100-040-200	Thrust Collar (Dynamic TO4B)
186794	1100-040-100	Bearing (T3/TO4B) Standard
186796	1100-040-140	Snap Ring (thin)
186796	1252-102-140	Retaining Ring S2A/D (J-Brg) >
186830	1100-040-320	Thrust Bearing
186835	1100-040-540	Lock Plate (TO4B Comp.)
186838	1100-040-500	Clamp Plate (TO4B Comp.)
186839	1100-040-480	CLAMP PLATE TURB
186840	1100-040-150	O Ring (B/Hsg TO4B)
186841	1100-040-160	Piston Ring TO4B ( Step.Turb)
186841	1252-302-170	Replaced by 1253 300 170
186842	1100-040-170	Piston Ring T04B C/E
186842	1252-102-170	Piston Ring S2A/D Comp. end >
186843	1250-403-561	Bolt
186844	1100-040-560	Bolt S2B
186847	1100-040-520	Lock Plate (TO4B Turb.)
186891	1250-404-320	Thrust Bearing 4MD ss 140964
188203	1200-050-100	Bearing (Cummins ST/ VT 50)
188379	1152-303-320	Thrust Bearing (4L-/HC3/3LKS) as 182561 but with oil filter
188552	1200-050-750	Service Kit T-ST-VT 50 Cum Lrg
188553	1200-050-751	Service Kit T-ST-VT 50 Cum Sml
188554	1200-050-280	Heat Packing (Cummins ST/VT50)
188555	1200-050-281	Fiber Insert (Cummins ST/VT50)
188556	1200-050-156	O Ring C/Hsg (Cumm ST/VT50)
188557	1200-050-150	O Ring (Seal Plate)Cum ST/VT50
188558	1200-050-155	O Ring (B/Hsg) Cummins ST/VT50
188559	1200-050-160	Piston Ring (Turb) CummST/VT50
188560	1200-050-170	Piston Ring (Comp) CummST/VT50
188562	1200-050-600	Bolt (2 piece Clamp) ST/VT50
188595	1200-050-450	Bearing Housing (T50-ST50-VT50)
188597	1200-050-300	Insert Seal Plate (S/Back) T50
188985	1252-419-100	Bearing S4A/D Std
188990	1100-180-140	Snap Ring.
189003	1200-050-436	Shaft & Wheel (T50) ss 1200050435
189007	1200-050-750	Service Kit T-ST-VT 50 Cum Lrg

OE Number	Melett No	Description
189089	1250-040-350	Shaft nut (4LE/F/GK)
189906	1252-139-100	Bearing S3A Std / Std
189909	1252-103-240	Thrust Ring S3 (replace 189909)
191750	1152-302-170	Piston Ring (H1C-H2C) Comp End
191819	1150-040-750	REPAIR KIT
191820	1150-040-750	REPAIR KIT
191996	1100-180-350	Shaft Nut T18
192510	1100-120-350	Shaft Nut. 5/16-24. T12
192511	1250-040-350	Shaft Nut 4L (7/16-20x8.5)
192512	1100-040-350	Shaft Nut (TO4B T3 RHT)
192512	1252-102-350	Shaft Nut S2A/D >
192871	1250-404-100	Bearing 4MD/4HD Std/Std
192879	1250-404-120	Bearing 4MD/4HD +10OD/-10ID (Grv ID & End)
192880	1250-404-124	Bearing 4MD/4HD +10 OD/Std ID (Grv ID & End)
193710	1252-102-155	O-Ring Comp Cover S2A
194118	1250-404-351	Shaft Nut 4MD (None Nylock)>
194281	1252-202-150	O Ring - Viton (Insert) S2A/S2B/S4D (Black)
194289	1252-212-220	Thrust Ring S2B
194787	1252-419-124	Bearing S4A/D +.010" OD / Std OD
194789	1252-419-120	Bearing S4 +.010" OD / -.010" OD
194798	1252-419-160	Piston Ring S3/S4/S81 T/End (replace 194798)
194914	1252-102-100	Bearing S2A Std. / Std.
194931	1252-202-100	Bearing S2B (Short) Std. / Std.
194932	1252-212-250	Wear Washer S2B Long
196021	1100-045-140	Retaining Ring
196284	1252-103-321	ssb 1252-203-320
196284	1252-203-320	Thrust Bearing S3A/S3B (replace 197752)
196370	1152-304-435	Shaft & Wheel HT3B
196397	1250-304-400	C/W HT3
196424	1252-212-600	Bolt (Stainless) S2B Turbine
196457	1252-202-150	O Ring (Insert) S2B (Orange) S2B/S4A
197087	1250-204-150	O Ring 4B (Orange)
197276	1252-102-220	Thrust Ring S2A
197470	1252-203-250	Wear Washer S3 (replace 197470)
197651	1250-403-300	Insert (.875" Bore) 3LD-4LE etc.
197752	1252-203-320	Thrust Bearing S3B / S3A
198689	1252-102-646	Lock Nut V-Band S2A
199113	1252-203-100	Bearing S3B Std OD/Std ID
199910	1252-419-100	Bearing S4 Std ssb 188985 with no washer
199973	1252-203-120	Bearing S3B +10 -10
310063	1100-040-750	Service Kit TO4B
310096	1100-040-400	Comp.Wheel (TO4B)
310187	1100-040-350	Shaft Nut (TO4B T3 RHT)
310247	1100-120-645	Nut. V Band clamp. T12
310250	1250-403-562	Bolt (Comp. Hsg) Metric
310278	1152-303-170	Piston Ring .750"
310279	1252-103-170	Piston Ring S3A/B C/End >
310416	1200-050-170	Piston Ring (Comp) CummST/VT50
310503	1150-400-170	Piston Ring
310630	1401-405-160	Piston Ring T/E TC06
310631	1401-405-170	Piston Ring TDO5/TDO6 Comp end
310637	1301-504-752	Service Kit 4LE/4LF
310649	1401-404-150	O Ring (Seal Plate TD04)
310650	1401-404-155	O Ring (TD04 B/Hsg / Chsg)

OE Number	Melett No	Description
310666	1401-404-145	Snap Ring TD04 (Insert retainer)
310667	1252-103-170	Piston Ring 3LM Comp End
310724	1150-400-170	Piston Ring
310727	1150-400-170	Piston Ring
310858	1301-027-435	Shaft & Wheel (K27 F/Back C/W) RHTssb 5327-120-5013 LHT
310887	1250-404-753	OVERHAUL KIT
310888	1250-404-752	Service Kit 4MD (Inc Gaskets)
310937	1301-028-150	O Ring K28
310938	1301-027-581	Washer (K27 Seal Plate)
310946	1301-027-101	Bearing (Grooved O.D. K27)
310947	1301-027-310	Oil Deflector (K26/K27)
310979	1301-027-610	Bolt (K27/K33/H2C/Garrett S/P to C/Hsg)
310982	1301-027-350	Shaft Nut (K24/26/27) 6mm RHT
310996	1301-026-620	Cap screws K26/27/ S/P to B/Hsg
311011	1301-026-750	REPAIR KIT
311013	1301-028-750	REPAIR KIT
311020	1252-212-140	Retaining Ring J-Brg S2B
311038	1301-027-320	Thrust Bearing (K27) 270 degree
311084	1251-704-435	Shaft & Wheel 4LGK
311413	1301-027-320	Thrust Bearing (K27) 270 degree
311496	1900-000-027	Gasket Oil Outlet T04B
311589	1252-102-645	Lock Nut M5 (Philidas nut)
311718	1301-027-360	Seal Plate (K27)
311721	1301-027-340	Turbine Back Plate (K27) (Cast)5327-165-2000
311725	1301-027-200	Thrust Spacer/Flinger (K26/27)
311740	1100-180-100	Bearing OD. Std / ID Std. T12 / T18
311741	1301-027-220	Spacer sleeve (K26/K27)
311742	1301-027-240	Thrust Ring (K26/K27)
311753	1301-027-750	REPAIR KIT
311754	1301-027-150	O Ring (K27 Comp. Hsg.)
311783	1301-027-750	REPAIR KIT
311807	1301-027-400	Comp Wheel K27 B/Curved 3060G
311808	1301-027-403	Comp Wheel K27 B/Curved 3064G
311809	1301-027-402	Comp.Wheel K27 Radial 2963U (Radial)
311810	1301-027-406	Comp. Wheel K27 B/Curved 2970N
311839	1301-027-450	Bearing Housing (K27 L/Turb)
311846	1101-661-750	Repair Kit TV61/71
311857	1252-201-170	Piston Ring C/End S1B
311861	1252-201-150	'O' Ring (Seal Plate) S1B
311862	1252-201-320	Thrust Bearing S1B
311876	1101-461-550	Lock Plate TV series
311882	1100-045-160	Piston Ring Step Bore(T12/45/51/TV )
311883	1100-045-170	Piston Ring TA45/ TA51/T18 /T 12 /T 6 C/E
311885	1100-180-320	Thrust Washer T12
311888	1101-061-200	Thrust Collar (TV61-81 T18A)ssb1101061200
311889	1100-180-220	THRUST SPACER T18A/TV71-81
311899	1100-180-190	Wear Washer (Bearing) T12 / T18
311901	1100-120-350	Shaft Nut
311902	1100-180-350	Shaft Nut T18
311903	1101-680-620	BOLT 1/4" x 20 1"Lg
312269	1301-036-750	REPAIR KIT
312292	1301-027-151	O Ring
312304	1301-027-100	Bearing (Smooth O.D. K27)
312325	1101-280-750	Repair Kit TV6/7/8

OE Number	Melett No	Description
312340	1152-303-435	Shaft & Wheel (HC3/K361) UNF T3
312342	1301-027-405	Comp. Wheel K27 Radial 2966V
312345	1100-045-610	Set Screw C.E. (M8 x 10) patched
312455	1252-212-100	Bearing S2B (Long) Std. / Std.
312553	1252-201-155	'O' Ring (Comp Cover) S1B
312553	1252-219-155	O Ring (C/Hsg) S1A/S1B/S1BG>
312697	1301-014-160	Piston Ring 14mm - CHECK RADIAL THICKNESS
312719	1252-102-320	Thrust bearing S2A/S2B (replace 312719)
312758	1252-101-100	Bearing S1A Std/Std
312758	1252-201-100	Bearing S1B Std. / Std.
312760	1252-201-140	Retaining Ring (J/Brg) S1B
312836	1301-027-455	Bearing Housing (K27 S/Turb)
312837	1301-027-342	Turbine Back Plate (K27) Stain/Steel Pressing (Medium dia)
312855	1301-027-438	Shaft & Wheel K27 RHT
312856	1301-027-436	Shaft & Wheel K27 (S/Back C/W) RHT
312861	1301-027-341	Heat Shield (Pressing)
312868	1100-040-160	Piston Ring TO4B( Step.Turb)
312868	1252-102-160	Piston Ring S2A/D Turbine end >
312957	1301-027-480	Clamp Plate (K27/3LKZ Turb)
313119	1301-027-455	Bearing Housing (K27 S/Turb)
313590	1102-015-351	Shaft Nut (M5 x 0.8 L.H.)
313627	1301-027-320	Thrust Bearing (K27) 270 degree
313713	1301-027-425	Comp. Wheel K27Bcur Sbk3262MGB
313783	1252-201-160	Piston Ring T/End S1B Std/Std
313861	1252-212-160	Piston Ring S2B Long Turbine End
314612	1252-103-161	Piston Ring - S3A (Komatsu) - T/End
315534	1253-200-160	Piston Ring S200 (Turb.)
315535	1253-300-160	Piston Ring S300 (Turb.)
315536	1253-400-160	Piston Ring S400 (Turb. 26mmOD)
315599	1252-201-600	Bolt T/Hsg S1B (Stainless)
316077	1152-301-150	O Ring (B/H-S/P H1C> H2A HC5A)
316093	1152-105-750	REPAIR KIT HC5A
316193	1252-203-161	Piston Ring S3B T/End (replace 316193)
316328	1100-120-645	Band Clamp Nut
316605	1100-025-350	Shaft Nut (M6 L.H.)
316615	1152-302-750	REPAIR KIT H2C
317324	1253-400-161	Piston Ring S3/S400 T/End.(replace 317324)
317589	1253-400-162	Piston Ring S400 (Turb. 22.5mm OD/Twin Ring Shaft)
318350	1250-040-751	Minor Kit All 4LE/4LF (Step & Smooth) replace 318350
318351	1250-040-751	REPAIR KIT 4L
318352	1152-304-750	REPAIR KIT HT3B
318355	1250-040-750	Minor Kit 4LE/F/G Step Bore (replace 318355)
318357	1250-404-753	Service Kit 4MD/4HD (replace 318357)
318364	1150-403-754	REPAIR KIT 3LD
318372	1100-040-750	Service Kit TO4B
318374	1252-201-750	Minor Repair Kit S1B (replace 318374)
318377	1252-102-750	Service Kit S2A
318386	1252-203-750	Repair Kit S3B (replace 318386 & 7)
318388	1252-203-751	Repair Kit S3B (replace 318388)
318391	1252-103-756	Repair Kit S3A (replace 318391)
318392	1252-103-757	Repair Kit S3A Komatsu (replace 318392)
319478	1252-102-646	Lock Nut V-Band S2A